

Product information

CASE CLEANER

600ML AEROSOL

DIRT RELEASE TECHNOLOGY

Designed to effectively clean fan coil and cassette cases and diffusers.

Formulated to clean and remove nicotine, grease and grime giving that just cleaned look.

- Effective and easy to use
- Removes nicotine, grease and grime
- Safe on most plastics and metal casework

PACKING & SHIPPING

Pack quantity:	12 x 600ML
Pack size (L x H x W):	270 x 205 x 300mm
Pack shipping weight:	8kg




INSTRUCTIONS

Shut the unit off. Shake can thoroughly before use. Hold can approximately 6" (15cm) from the surface to be cleaned and spray evenly. Do not spray onto live electric motors or controls. Wait a few moments for Case Cleaner to break down the dirt and wipe clean with a dry cloth. Before use test Case Cleaner on a non-conspicuous area.

Full safety information on following pages.

For professional use only.

Keep out of reach of children.



DANGER

H222 Extremely flammable aerosol. **H229** Pressurised container, may burst if heated. **P210** Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. **P211** Do not spray on an open flame or other ignition source. **P251** Do not pierce or burn, even after use. **P410+P412** Protect from sunlight. Do not expose to temperatures exceeding 50°C/122°F. **P102** Keep out of reach of children. **P501** Dispose of contents/container in accordance with local regulations. **P260** Do not breathe vapour/spray. **P271** Use only outdoors or in a well-ventilated area. <5% non-ionic surfactants.